

### Quick Guide – Tier 1 Room (TV or Projector)


Calvin Hall – 121, 152, 171, 173, 175, 176, 177, 179, 221, 229, 269, 273, 274

Gurley Hall – 1234, 1239

Zollinger – 102, 103, 119

Tier 1 control panels are similar to what you were using previously.

- Turning ON the system lowers the screen and turns on the projector.
- Turning OFF the system raises the screen and turns off the projector.
- Connection is through the HDMI cable from the panel to your computer.
- For Tier 1 rooms with a TV the panel functions similarly turning the display on and off.
- Volume controls are the – and + symbols at the bottom of the control panel.



### Quick Guide – Tier 3 Room

Calvin Hall – 261, 266, 268

Tier 3 controls are via desk mounted touchscreen controller.

- Turning ON the system lowers the screen and turns on the projector.
- Turning OFF the system raises the screen and turns off the projector.
- Connection is through the HDMI cable from the controller to your computer.
- Volume controls via the slider in the bottom right of the controller.



## Quick Guide – Tier 4 Room

Calvin Hall – 119, 174, 182, 184, 220, 268

Health Careers – 133, 109, 105

SSTC – 108, 162, 172, 182

Tier 4 controls are via desk mounted touchscreen controller.

- Turning ON the system lowers the screen and turns on the projector and camera.
- Turning OFF the system raises the screen and turns off the projector and camera.
- Connection is through the HDMI cable from the controller to your computer.
- Volume controls via the slider in the bottom right of the controller.
- Additional controls available for camera Pan/Tilt/Zoom.

